## FIG. 36 WINDOW JAMB - Timber Hold flashing off wrap using kick-out batten or galv. clouts Air seal 200mm Supercourse 500 polythene flashing, clout fixed over building paper Timber joinery ex 75 x 25 H3.2 molding Brick tie within 200mm of opening Brick veneer